


A30-6 MASSAGE CHAIR ***Operation Instructions***

SAVE THESE INSTRUCTIONS



Thanks for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly before operation. Please pay more attention to some important safety warning and keep this manual book properly for future use. Note: Our Company reserves the right to revise the design and description of this product without any further notice. Please refer to the actual color of this product.

CONTENTS

Safety and maintenance	02
Name and function of components	04
Function & Efficacy	05
Method of usage	06
Product specification	13

1. IMPORTANT SAFETY WARNING.



- Don't allow children to touch moveable part of this product.
- Please use well-grounding power supply suited to this product.
- Please pull out the plug after use or before cleaning to avoid injury or Damage to the product.
- Please operate this product according to this manual instruction.
- Don't use accessories which are not recommended.
- Don't use this product outdoors.
- Please read this manual instruction carefully before operation.
- Any other usage that is not listed in this manual instruction is forbidden.
- 20 minutes of usage each time is recommended.
- Please don't use it if the leather is broken or damaged.
- Please don't use it if the cover or leather is damaged.
- Please don't use it if the radiator hole is covered or blocked.
- Please don't drop anything into this product.
- Please don't fall asleep while using this product.
- Please don't use it if drunk or feel unwell.
- Please don't use it within one hour after having meal.
- Please don't make the massage function too strong for avoiding Injury.

2. Environment for usage.

- Please don't use it under high temperature and moist environment such as bathroom.
- Please don't use it immediately while the environmental temperature changes sharply.
- Please don't use it under heavy-dusty or caustic environment.
- Please don't use it where there is not enough space or not good ventilation.

3. People who are not suitable to use this product.

- People who are suffering from osteoporosis are not suitable to use this product.
- People who are suffering from heart disease or carrying electronic medical equipment such as heart pacemaker are not suitable to use this product.
- People who are suffering from fever are not suitable to use this product.
- Pregnant women or women that are in menses period are not suitable to use this product.
- People who got injured or skin disease are not suitable to use this product.
- Children under 14-year old or people mentally unbalanced without being Supervised are not allowed to use this machine.
- People who are told by doctor to have rest or people who feel unwell are not suitable to use this product.
- People whose bodies are wet are forbidden to use this product.

4. Safety.

- Check the voltage if it is suitable to the specification of this product.
- Don't use wet hand to pull the plug.
- Don't make water go inside this product to avoid electric shock or cause damage to this product.
- Don't damage the wires or change the circuit of this product.
- Don't use wet cloth to clean the electric parts such as switch and plug.
- Be away from this product under power cut state to avoid injury if the power comeback suddenly.
- Stop using this product while it works abnormal, and please consult local agent immediately.
- Stop using this product if you feel unwell, and please consult health care doctor.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its Service agent or similarly qualified persons in order to avoid a hazard.


5. Maintenance.

- This product should be maintained by certain appointed agents, users are prohibited to disassemble or maintain by themselves.
- Please don't forget to cut the power after usage.
- Don't use this product if the socket looses.
- If this product will be left unused for long, please curl up the wires and reserve this product in dry and dustless environment.
- Don't reserve this product under high temperature or near fire and avoid longtime direct sunshine.
- If the detachable cord / supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a Hazard.
- Please clean this product by dry cloth. Don't use thinner, benzene or alcohol.
- The mechanical components of this product are specially designed and made, it is not necessary to be specially maintained.
- Don't use edged res to thrust this product.
- Don't roll or pull this product above uneven ground, it should be lifted before moving.
- Please use it intermittently; don't make this product work continuously for long.


6. Solution of ordinary malfunctions.

- It is nature movement voice if the motor sounds while in usage.
- If the controller can't work normally, please check the plug and socket if they are connected strongly and make sure the switch is turned on.
- If the rated working time is over, the product will automatically activate the power-off button; If this product works continuously for long, the temperature protector will make the product automatically power-off, it should be used again after half an hour's rest.

Name and function of components



1. Pillow pad
2. Controller
3. Armrest
4. Seat pad
5. Calf support
6. Massage points of
acupuncture points on sole
7. Backrest pad



8. Backrest cover
9. Vent
10. Controller support
11. Moving sliding wheel
12. Power cord and plug
13. Power switch
14. Fuse box

04

Function & Efficacy



Function

- Designed with a set of vertically movable, four-wheel drive muted massage hands.
- Programmed with five emulational massage methods of shiatsu, kneading, flapping, knocking and synchronous kneading & flapping.
- Automatic checking the position of shoulder.
- Designed with four special automatic massage function (comfort, relax, ache-relieving, fatigue recovery)
- Automatic massage for upper body (four mode options: overall, neck and shoulder, back and waist, and fixed therapy)
- Manual massage for upper body (three massage area options: overall, partial and fixed, with five levels of adjustable speed. In the state of fixed massage, the massage head can move up and down. In the state of flapping, shiatsu and knocking, the width between the two kneading balls is adjustable with three levels: wide, medium and narrow.
- Two pairs of mastoids set in foot positions to apply strengthened massage to the peripheral area of the calf muscle, cheng shan points and wai qiu point and the reflecting area of the sole yong quan point(foot point) such as lung, heart, liver, gallbladder, kidney, duodenum, pancreas, head, shoulder, esophagus, eye, ear, thyroid gland and trachea.
- With vibration function in buttocks, and the strength is adjustable.
- Design with the calf rest and back rest can be reclined and declined separately, and the calf can be reclined and declined together with the back rest.
- Restoring the massage hands automatically.

Efficacy

- Relieve fatigue.
- Promote the blood circulation
- Relax the stressed muscle
- Ease the tensed muscles
- Relieve the nervous pain
- Relieve the muscular ache

05




1. Switch on the power supply of the whole unit




2. Operation methods of the remote control

(1) Start/Stop the massage of the whole unit




(2) Start massage

- ① Press red switch to start the massage, and the massage chair turns to lying Position automatically.
- ② First detect the massage points of the upper body and the position of shoulder. The machine will send ticks to prompt the completion of detection. This time a user may adjust the position of shoulder within a small range based on his (her) size by pressing down Up/Down buttons. The machine will enter the massage function automatically in case no adjustment of shoulder position is made within 5-10 s.
- ③ Adjust the position of shoulder.











Suitable shoulder position



Method of usage

(3) Individualized automatic massage:



















Name	Buttons	Massage aim	Characteristic	State displayed
Individualized automatic massage	 COMFORT	For comfort	Relax the bones and muscles	Auto 01
	 EASE	For relaxation	Promote the blood circulation	Auto 02
	 ACHE RELIEVING	For improving ache	Perform deep massage on the finger-pressed points to ease the ached body part	Auto 03
	 FATIGUE RECOVER	For relieving fatigue	Recover from the fatigue and resume the vigor of body	Auto 04

Name	Buttons	Massage aim	Characteristic	State displayed
Automatic massage	 FULL BODY	Massage in full range	Perform massage mainly on the whole upper body	Auto F1
	 NECK & SHOULDER	Massage of neck and shoulder	Perform massage mainly on neck and shoulder	Auto F2
	 BACK & WAIST	Massage of back and waist	Perform massage mainly on back and waist	Auto F3
	 FIXED THERAPY	While selecting the fixed point massage site under the mode of automatic massage, the lowest position of waist will be taken as the baseline, and 8 positions above the baseline will be divided for the automatic massage. VFD auto mode will display sequentially (F4, F5, F6 ... F9, FA, FB). Any functions under the mode of automatic massage may be selected by manipulating UP/DOWN key for the fixed point massage.		





08

Method of usage

(4) Manual massage:

Functions	Buttons	State of description and display	Adjustment of massage ball
Massage modes	Finger Pressing  SHIATSU		Speed, width
	Kneading  KNEAD		Speed
	Patting  FLAP		Speed, width
	Kneading And patting  KNEAD&FLAP		Speed
	Knocking  KNOCK		Speed, width
Relaxation of back	 BACK STRETCH	Massage at fixed Points 	UP key: move the massage mechanism upwards under the modes of fixed point massage and local massage to locate accurately the massage points; DOWN key: move the massage mechanism downwards under the modes of fixed point massage and local massage to locate accurately the massage points.
		Reciprocal massage in a small (local) range 	
		Reciprocal massage in the upper body (whole range) 	
Speed	 SPEED	Speed 	There are 5 selectable ranges of speed
Width	 WIDTH	Width 	There are 3 selectable ranges of width






(5) Vibration

Functions	Buttons	State of description and display
Buttock Vibration	 BUTTOCK VIBRATION	Buttocks vibration function button 
Intensity	 INTENSITY	Buttocks vibration strength options 







09

Method of usage

(6) Pneumatic massage

Function	Buttons	Description	Characteristics
Lower body		Turn on or off the function of pneumatic massage for the lower body	There are two selectable ranges of intensity
Buttocks		Turn on or off the function of pneumatic massage for buttocks	There are two selectable ranges of intensity
Feet		Turn on or off the function of pneumatic massage for feet	There are two selectable ranges of intensity
Intensity of air Pressure		Turn on or off the intensity of pneumatic massage	Divided into two ranges: Strong and Weak
Calf stretching		By pressing down this button, the function of leg stretch will be enabled under the mode of pneumatic massage for lower body or feet.	

(7) Adjustment of angles of calf support and backrest


Calf lifting		Button for lifting up the calf support: hold this button down to lift up the calf support, and release it to lock the calf support
		Button for lifting down the calf support: hold this button down to lower the calf support, and release it to lock the calf support
Backrest lifting		Button for lifting up the backrest: hold this button down to lift up the backrest slowly, and release it to lock the backrest
		Button for lifting down the backrest: hold this button down to lower the backrest slowly, and release it to lock the backrest
Rise, sit and lie	 Left	Rise & sit button 1: hold this button down to lift up the backrest slowly; meantime the calf support is lowered slowly; release it to lock them both
		Lie button 1: hold this button down to lift down the backrest slowly; meantime the calf support is lowered slowly; release it to lock them both
	 Right	Rise & sit button 2: hold this button down to lift up the backrest slowly; meantime the calf support is lowered slowly; press any other button (excluding Lie button 2) to lock them both
		Lie button 2: hold this button down to lift down the backrest slowly; meantime the calf support is lowered slowly; press any other button (excluding Rise & sit button 2) to lock them both

Method of usage

3. Switch off the power supply to finish the massage

(1) All massage functions will be stopped at once by pressing down the red switch button during the massage process, and backrest and calf support will reset automatically; or all massage functions will be stopped when the timed massage is completed, but backrest and leg support do not reset.


(2) Switch off the power supply of the whole unit.



4. The padding and back cushion assembling and operation massage
Using the cushion which can reduce the neck & shoulder kneading of the pillow, can determine according to your demands whether to use the pillow cushion or not (recommend using the pillow cushion)..

(1) backs of cushions connect back through zipper. (2). pillow cushion and back through is it spike joining to glue cushion.


WARN: Can't raise the back cushion to use, in case of causing you hurt.



Method of usage


5. Installation and use of the controller and table tray

(1) Install the controller shelf on the massage chair. (2) The controller can rotate 180 degrees from head to foot. (3) The controller can be controlled and rotated 360 degrees



6. How to move the chair

Make sure wires are not in your way before you turn the back backward to a proper angle with the gravity center of the chair falls onto the casters. Then pull the chair forward or backward as you wish.



Product specification

Name: Massage Chair

Model: A30

Configure: 06

Rated voltage: 110-120V~ 60Hz
220-240V~ 50Hz/60Hz

Rated power input: 150W

Rated time: 15Min

Safety structure: Class I

Material introduction: PVC, PA, steel parts and electric & electron parts

MATERIAL	PU	LEATHER	CLOTH	WOOD

